

## Using the Wing WiFi Card



Certain UPRtek models comes with the Wing WiFi SD card which allows users to use their smartphone to wirelessly control measurements and view results as they are measured. Download the appropriate app through the App Store or Google Play to get started. If you are unsure which app to download, contact the factory.

### Wireless Connection Setup

1. After installing the app, insert the Wing SD card into the SD card slot
2. Turn on WiFi setting on your phone and connect to **UPRtek\_Wing** or **MK350-WiFi**
3. Open the app for the spectrometer
4. Happy measuring!

Perfer to watch an instructional video? Click here: [https://youtu.be/gzh\\_W-dEcXA](https://youtu.be/gzh_W-dEcXA)

